

INCLUDES

**Full impression including full helix, crus of the helix, tragus and antitragus**

DEPTH

**Past 2nd bend**

MATERIAL

**High-viscosity silicone**

BITE BLOCK

**1-2" recommended**

1. Full impressions are required of each ear. This includes the full helix, crus of the helix, tragus and antitragus.
2. The impression must go past the second bend of the ear canal.
3. Only a high-viscosity silicone impression material should be used.
4. Use a 1-2" bite block throughout the entire process to reduce movement. Patient must keep completely still in order to insure a good fit and optimal seal.

Great Impression Examples



Fill out and include the below form in the package along with your ear impressions. This step is necessary for us to match your impressions with your order.

For peace of mind, we recommend using a shipping service that provides a tracking number. Ship your ear impressions to:

Maytak Audio Impressions  
3740 Boiling Springs Rd #3  
Boiling Springs, SC 29316

**Name** \_\_\_\_\_ **Order #** \_\_\_\_\_

**Email** \_\_\_\_\_ **Phone #** \_\_\_\_\_

**Notes** \_\_\_\_\_

\_\_\_\_\_